
BCTMP Technology: Development and Applications

Eric C. Xu (Ph. D.)


History of BCTMP Development: 1st Generation (1G)


1G BCTMP (started in 1980's): C+TMP+B



IP Svetogorsk

Principle flowsheet (Today)








History of BCTMP Development: 2nd Generation (2G)


2G BCTMP (started in 2000's, Yueyang P-RC APMP):






- Xu, E.C., "A New Concept In Alkaline Peroxide Refiner Mechanical Pulping", International Mechanical Pulping Conference, Houston, USA, (May 24--26, 1999).
- Zhang, D.-J., Guo, Y.-W. & Xu, E. C. "Successful Start-Up And Commercial Operation Experience With P-RC APMP At Yueyang Paper Mill", Proceeding of 2005 International Mechanical Pulping Conference, Oslo, Norway, (June 6-9, 2005).

Andritz 2G BCTMP: P-RC APMP with 2xPT+2xBleaching




Devoplment of 2G BCTMP: LCR at 2nd Stage Refining



Xu, E.C, Koefler H. and Antensteiner P., "Some Latest Developments In Alkaline Peroxide Mechanical Pulping, Part 2: Lower Consistency Refining at Secondary", Preprint of 88th Annual Meeting of PPTA of Canada (Jan. 28-Feb. 1, 2002).


Guo, Y., Xu, E.C. and Teubner D., "Comparison Between High and Low Consistency Refining at Yueyang P-RC APMP Mill", Proceedings of 2009 IMPC, Sweden, (May 31 - June 4, 2009)

Common 2G BCTMP Flowsheet: (Simplified)




Andrtiz 2G BCTMP Fiber Line: (P-RC APMP)

- APP-Jingui, China, (750-1000adt/d, 2010)



Valmet 2G BCTMP Fiber Line:


- SE-Beihai, China (700-850adt/d)



(Peng, IMPC 2018)

Main Characteristics of 2G BCTMP Technology

- Use less energy than 1G BCTMP
- Consist of 4 basic treatment steps:
 Chemical -> Mechanical -> Chemical -> Mechanical
- How to do each step depends on nature of raw matrial used, product quality, investment and others...



Why 2G BCTMP use less energy than 1G BCTMP


Applied 2 basic and well-known important "rules" in HWD BCTMP pulping:

- Alkali peroxide treatment reduces refining energy:
 - > fibers are easier to be separated and fibrillized
 - more and ealier used -> lesser energy consumed
- High intensity refining uses less energy than low intensity refining:
 - > LCR has much higher refining intensity than HCR
 - More LCR -> lesser energy consumption

From 1G to 2G:

history of how to better use chemical and refining intensy


➤ 1G BCTMP (From 1980's):




3G? how?

From 2G to 3G: logical development of BCTMP history


➤ 1G BCTMP (From 1980's):












From 1G to 3G BCTMP:

Moving bleaching chemcial treatment earlier in pulp development process, helps utilise more chemical effest and more LC refining to reduce more energy consumption

Different Generation of BCTMP: Using LC Refining


- 200mL CSF as example



Specific Energy Consumption (SEC)

Different Generation of BCTMP

- Earlier the bleaching, the less energy consumption ("freeness/SEC slope" is steeper)
- Based on same total chemical charge and same type refining



Why i-BCTMP is better than 2G BCTMP

Combine chip press and primary refiner in one step, using thermal shreder to generate wood shreds

wood structure is more open than pressed and macerated chips
easier for chemical penetration and distribution
use less energy than conbinaiton of primary refining and MSD
wood shreds should not be too large to cause problems with chemical
penetration; and not too small to use too much energy

Apply most or all the chemicals on the wood shreds to Maximize the chemical effect on energy saving Improve chemical efficiency

Energy distribution (one example for HCR at 2nd stage): 2G BCTMP

MSD+Primary: 500-600kwh/t

Post Refining: 250-600kwh/t)

3G BCTMP (i-BCTMP)

TS: 150-350 kwh/t

Post Refining: 350-650kwh/t

Basic Principles of 3G BCTMP (i-BCTMP) Technology


Use high pressure (high temperature) saturated steam and Thermal Shredder (TS), to produce softened wood shreds:

wood chips are softened first at high tempreture to prevent or reduce damages to wood fibers during shredding

shred size should be controlled and not be too big or too coarse to avoid excessive energy consumption and damages to the fibers Chemical treatment can be made before, during and after the shredding, depending on nature of chemical treatment and product

To maximize chemical efficiency and reduce energy consumption and, hence, improce pulp yield.

After chemical treatment: washing, refining and screening



Key Component of i-BCTMP: Thermal Shredder System


Thermal Shredder system consist of PSF, thermal tube, thermal shredder:

SPF: feed matrial and keep saturated steam

Thermal Tube: soften wood chips (can be horizontal or vertical)

Thermal Shredder: shred wood chips into wood shreds

Saturated Steam: pressure/temperature and time need to be properly controlled




Thermal Shredder Sytem

Application of i-CTMP in BCTMP): i-BCTMP


i-BCTMP:

- i improved/innovated
- B bleached
- C chemical
- T therma
- M mechanical
- P pulping



Thermal Shredder

Typical 3G BCTMP (i-BCTMP) Flowsheet: simplified



Reject Chest

Dilution

Storage Tower


Chest



Chest

3G vs 2G BCTMP: different pulp development road

2G BCTMP:



Comparison Between 3G ad 2G BCTMP: (Simplified)

Less energy & chemical consumption, and higher pulp yield (lower production cost) Simpler flowsheet and less equipment (less investment cost)

Easier to operate and less wear and tear on equipment (less operation cost)
Can handle more different raw materials and wider changes in raw materials

